

How to Install Drawer Runners



Tools Required:




Cordless Drill

Step 1:

Collect all of the required parts for your goFlatpacks product. You will need:

1. Left Drawer Runner
2. Right Drawer Runner
3. Euro Screws



Step 2:

First let's start with installing the **Left Side Runners**. Turn your cabinet on the side to make installation easier.



Step 3:

Place the first **Drawer Runner** in the cabinet and line up with the pre-drilled drawer runner holes.

The front edge of your drawer runner should sit a couple of millimetres back from the front of your cabinet - so use the appropriate hole on the runner.



Step 4:

Affix your first Euro Screw into the drawer runner. Be careful not to over-tension the screw.

Repeat the process for the remaining screw holes on the runner.



Step 5:

You may have to slide the **Drawer Runner** forward to access the back screw hole.



Step 6:

Place the next **Drawer Runner** in line with the pre-drilled holes and repeat the process.



Step 7:

Once you have installed all of the **Drawer Runner** for one side, flip your cabinet and repeat the process for the other side.



Step 8:

To install your drawers on your runners, simply place the drawer on top of the runners and push them back into the cabinet until you hear both sides click into place.



Step 9:

Congratulations! Your goFlatpacks Drawer Runners are now installed.

